



Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

Warranty & Customer Service

SCAN FOR



e-Warranty

e-Warranty Registration at www.khind.com.my/e-warranty.html

KHIND MARKETING (M) SDN. BHD. (199701026923) (442421-A)

No. 2, Jalan Astaka U8/82, Bukit Jelutong, 40150 Shah Alam, Selangor, Malaysia.

Customer Service Hotline: 03-7839 2090 / 018-223 3389 (WhatsApp only)

Service Centre Operating Hours: 8.30am – 6.00pm (Monday - Friday)

Closed on Saturdays, Sundays and Public Holidays

Waranti & Perkhidmatan Pelanggan

IMBAS UNTUK



e-Waranti

Pendaftaran e-Waranti di www.khind.com.my/e-warranty.html

KHIND MARKETING (M) SDN. BHD. (199701026923) (442421-A)

No. 2, Jalan Astaka U8/82, Bukit Jelutong, 40150 Shah Alam, Selangor, Malaysia.



Hotline Perkhidmatan Pelanggan: 03-7839 2090 / 018-223 3389 (WhatsApp sahaja)

Waktu Operasi Pusat Perkhidmatan: 8.30am – 6.00pm (Isnin-Jumaat)

Ditutup pada hari Sabtu, Ahad dan Cuti Umum

mistral

16" DC Stand Fan with Remote MSF1652DC



STAND FAN

Please read this instruction manual thoroughly before operating and keep it for future reference

⚠ IMPORTANT SAFETY INSTRUCTIONS

1. Ensure that the fan is switched off from the supply mains before removing the fan guard for cleaning.
2. Use this fan with specified voltage as stated on the rating sticker. Before connecting fan to the AC mains, make sure the voltage specified corresponds to the AC supply to your house.
3. Do not insert finger or other objects into the fan guard.
4. Do not attempt to repair the fan. Always return to our authorised service agents for repairs.
5. Do not immerse the motor assembly or any parts of the fan inside the water or other liquids.
6. This appliance is intended for household use only. Do not use the appliance outdoors or near windows. Rain drops may cause electrical hazards.
7. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
8. Do not operate this appliance without a fan blade, broken or bent fan blade.
9. Handle fan blade with care during cleaning.
10. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
Children should be supervised to ensure that they do not play with the appliance.
11. The ventilation holes of rear motor cover must be free of dust & dirt. Please use a soft cloth or vacuum cleaner to clean it frequently.

WARNING: Do not use this appliance in high temperature and high humidity environment.

Cleaning & Maintenance


1. Keep the fan clean. Use it in dry place.
2. Do not bend the blades when installing & maintaining.
3. Wipe away dirt with clean soft cloth, soap & water to clean the fan. Wipe until dry.
4. Do not use the following as cleaning solvents: petrol, thinner or benzene for cleaning.
5. Use mild soap with damp cloth or sponge to clean the plastic parts.

Clean Fan Guards & Fan Blades

1. Unblock the guard ring lock by removing the safety screw.
2. Remove the front fan guard
3. Remove the blade locking screw.
4. Detach the fan blade.
5. Remove the rear fan guard.
6. Wash detached components with soft cloth and mild soap or mild detergent.
7. Wipe dry with a soft cloth. Note that excessive rubbing with a soft cloth may scratch the components.
8. Clean dust and dirt that have accumulated on the motor shaft.

INTRODUCTION OF PARTS

1. Centre Ring
2. Front Guard
3. Guard Ring
4. Blade Knob
5. Blade
6. Guard Nut
7. Rear Guard
8. DC Motor
9. Fan body
10. Control Panel
11. Power cord
12. Thumb screw
13. Internal Pole
14. Connector (Adjustment ring)
15. Standing Pole
16. Base
17. Base screw
18. Remote control



*Pictures are for illustration purposes only.

PRODUCT TECHNICAL PARAMETERS


Model	MSF1652DC
Voltage	100-240V ~ 50/60Hz
Power	30W
Blade Size	16"
Blade Material	ABS Plastic
Blade Quantity	5
Power Consumption	Low: 20W High: 30W
Fan Speed	Low: 379rpm High: 1248rpm
Air Delivery	82.05m³/min 2897CFM
Noise Level	57.3dB
Effective Coverage Area	26m²
Speed Setting	10
Net Weight	5.5kg
Gross Weight	6.4kg
Product Dimension (LxWxH)	445 x 400 x (1140-1320)mm

*Specifications are subject to change without prior notice.


HOW TO USE

Installation

1. Open the box and check the parts by referring to the part illustration drawing.
2. Insert the standing pole into the base and fasten the base screw. (Refer to Fig. 1)
3. Loosen the connector and adjust the inner pole to the desired height.
(Note: If you can't find the inner pole, it might have slid into the standing pole. Simply pull it out.) (Refer to Fig. 2)
4. Loosen the thumb screw on the back of the fan body and attach it to the inner pole.
5. Fasten the thumb screw in alignment with the groove on the inner pole. (See Fig. 3)



6. Remove the spinner and the plastic nut from the front side of the motor.
7. Fix the rear guard to the motor then tighten the plastic nut again. (Fig.4)
8. Discard PVC sleeve on shaft. Insert the blade into shaft, make sure the stopper pin is fitted into groove of the blade. Turn the spinner anticlockwise to tighten the blade. (Fig.5)
9. Fix both grilles with Guard Ring (Part 3) and then use screwdriver to tighten the locking screw. (Fig.6)



OPERATION

ON/OFF KEY

The key is for switching on the fan. The fan will start at low speed. Press this key again if the fan needs to be switched off.

SPEED KEY

After the fan has started, press this key to select the fan speed. The sequence is increasing when this key is being pressed repeatedly. The maximum speed is 10.

TIMER KEY

The timer key can be pressed repeatedly to increase the air delivery time in one-hour increments, up to a maximum of 10 hours. Do not use the timer function if continuous fan operation is required, as none of the timer LEDs will be illuminated.

OSC KEY

Press this key to enable the oscillation function. To select a specific direction, press the key while the fan is oriented in that direction. Otherwise, manually rotating the fan head will achieve a wider oscillation range.

MODE KEY

Press this key to select mode. The sequence is normal, natural and sleep when this key being pressed repeatedly.

NORMAL WIND MODE


The fan blows continuously based on the selected speed.

NATURAL WIND MODE

The fan operates at speeds programmed to mimic natural wind. Each time the gear shifts, it runs for 3 seconds before moving to the next gear, cycling continuously.


SLEEP WIND MODE

The fan operates at a speed preset by a computer program that simulates "sleep wind." This function offers five fixed gears (1 to 5). Once activated, you can adjust the gear using the key switch.



REMOTE CONTROL OPERATION

1. Point the remote control towards the fan press the desired key.
2. The remote control will work as distances of up to roughly five meters and the angle of 30 degree from panel LED display.
3. Ensure there is no direct sunlight facing the same direction.
4. Remove batteries before disposing of the remote control.



Remote control



CR2025 Battery



Battery cover

BATTERY

1. Slide the battery compartment cover.
2. Insert the batteries, and make sure that the batteries are placed as shown in the Battery Compartment diagram.
3. Slide back the battery cover.

Notes: Do not use rechargeable batteries.

TILT ADJUSTING

To adjust the air flow upward or downward, push the guards lightly to the desired direction.

HEIGHT ADJUSTING

The lower standing pole can be taken off to adjust to a shorter height.

MEMORY FUNCTION

After manually shutting down in the current working mode, when starting up again, it will enter the working state before shutdown.

⚠ Maklumat Langkah-langkah Keselamatan

1. Pastikan kipas dimatikan daripada bekalan utama sebelum menanggalkan pelindung kipas untuk pembersihan.
2. Gunakan kipas ini dengan voltan yang tertentu seperti yang dinyatakan pada pelekat penilaian. Sebelum menyambungkan kipas ke saluran kuasa AC, pastikan voltan yang dinyatakan sepadan dengan bekalan AC ke rumah anda.
3. Jangan masukkan jari atau objek lain ke dalam pelindung kipas.
4. Jangan cuba membaiki kipas. Sila sentiasa kembali kepada ejen servis kami yang sah untuk pembaikan.
5. Jangan rendam pemasangan motor atau mana-mana bahagian kipas ke dalam air atau cecair lain.
6. Perkakas ini bertujuan untuk kegunaan dalam rumah sahaja. Jangan gunakan perkakas di luar rumah atau berhampiran tingkap. Air hujan boleh menyebabkan bahaya elektrik.
7. Jika kabel bekalan rosak, ia mesti diganti oleh pengilang, ejen perkhidmatannya atau pihak berkeelayakan yang serupa untuk mengelakkan bahaya.
8. Jangan kendalikan perkakas ini tanpa bilah kipas, bilah kipas yang patah atau bengkok.
9. Uruskan bilah kipas dengan berhati-hati semasa pembersihan.
10. Perkakas ini bukan untuk digunakan oleh orang kurang upaya (termasuk kanak-kanak) fizikal, deria atau kemampuan mental, atau kurang pengalaman dan pengetahuan, melainkan mereka dikawalselia atau mendapat tunjuk ajar yang sewajarnya berkaitan penggunaan perkakas ini oleh orang yang bertanggungjawab terhadap keselamatan mereka.
Kanak-kanak perlu dikawalselia bagi memastikan mereka tidak bermain dengan perkakas ini.
11. Lubang pengudaraan penutup motor belakang mestilah bebas daripada habuk & kotoran. Sila gunakan kain lembut atau vakum untuk membersihkannya dengan kerap.

AMARAN: Jangan gunakan perkakas ini pada suhu tinggi dan kelembapan yang tinggi.

Pembersihan & Penyelenggaraan


1. Pastikan kipas bersih. Gunakannya di tempat yang kering.
2. Jangan bengkokkan bilah kipas semasa pemasangan & penyelenggaraan.
3. Lap kotoran dengan kain lembut yang bersih, sabun & air untuk membersihkan kipas. Lap sehingga kering.
4. Jangan gunakan bahan berikut sebagai pelarut pembersih: petrol, penipis atau benzena untuk pembersihan.
5. Gunakan air sabun yang lembut dengan kain lembap atau span untuk membersihkan bahagian plastik.

Membersihkan Penghadang Kipas & Bilah Kipas

1. Buka gegelung kunci penghadang dengan menanggalkan skru keselamatan.
2. Tanggalkan pelindung kipas depan.
3. Tanggalkan skru pengunci bilah.
4. Keluarkan bilah kipas.
5. Tanggalkan pelindung kipas belakang.
6. Bersihkan komponen yang ditanggalkan dengan kain lembut dan air sabun yang lembut atau detergen yang lembut.
7. Keringkan dengan kain lembut. Sila ambil perhatian bahawa gosokan berlebihan dengan kain lembut boleh mencalarkan komponen.
8. Bersihkan habuk dan kotoran yang terkumpul pada shaf motor.

Pengenalan Bahagian

1. Cincin Tengah
2. Pelindung Hadapan
3. Cincin Pelindung
4. Tombol Bilah
5. Bilah Kipas
6. Nat Pelindung
7. Pelindung Belakang
8. Motor
9. Tombol Hayun
10. Badan Kipas
11. Butang Kelajuan
12. Kabel Kuasa
13. Skru Ibu Jari
14. Tiang Dalam
15. Penyambung (Cincin Pelaras)
16. Tiang Berdiri
17. Tapak
18. Alat Kawalan Jauh



*Gambar adalah untuk ilustrasi sahaja.

SPESIFIKASI PRODUK

Model	MSF1652DC
Voltan	100-240V ~ 50/60Hz
Kuasa	30W
Saiz Bilah	400mm
Bahan Bilah	ABS Plastik
Kuantiti Bilah	5
Penggunaan Kuasa	Rendah: 20W Tinggi: 30W
Kelajuan Kipas	Rendah: 379rpm Tinggi: 1248rpm
Penghantaran Udara	82.05m³/min 2897CFM
Tahap Kebisingan	57.3dB
Kawasan Liputan	26m²
Tetapan Kelajuan	10
Berat Bersih	5.5kg
Berat Kasar	6.4kg
Dimensi Produk (PxLxT)	445 x 400 x (1140-1320)mm


*Spesifikasi tertakluk kepada perubahan tanpa notis terlebih dahulu.

CARA-CARA PENGUNAAN


Pemasangan

1. Buka kotak dan periksa semua bahagian dengan merujuk kepada ilustrasi bahagian.
2. Masukkan tiang berdiri ke dalam tapak dan ketatkan skru tapak. (Rujuk Rajah 1)
3. Longgarkan penyambung dan laraskan tiang dalam ke ketinggian yang diinginkan. (Nota: Jika tiang dalam tidak kelihatan, ia mungkin telah tergelincir ke dalam tiang berdiri. Tarik keluar untuk menggunakannya.) (Rujuk Rajah 2)
4. Longgarkan skru ibu jari di bahagian belakang badan kipas dan pasang pada tiang dalam.

5. Ketatkan skru ibu jari sejajar dengan alur pada tiang dalam. (Rujuk Rajah 3)



6. Tanggalkan pemutar dan nat plastik dari bahagian hadapan motor.
 7. Pasang pelindung belakang pada motor, kemudian ketatkan semula nat plastik. (Rujuk Rajah 4)
 8. Buang sarung PVC pada aci. Masukkan bilah ke dalam aci, pastikan pin penghenti masuk ke dalam alur bilah. Pusing pemutar lawan arah jam untuk mengetatkan bilah. (Rujuk Rajah 5)
 9. Cantumkan kedua-dua gril menggunakan Cincin Penghadang (Bahagian 3), kemudian gunakan pemutar skru untuk mengetatkan skru pengunci. (Rujuk Rajah 6)



OPERASI

BUTANG ON/OFF

Butang ini digunakan untuk menghidupkan kipas. Kipas akan bermula pada kelajuan rendah. Tekan butang ini sekali lagi jika kipas perlu dimatikan.

BUTANG SPEED


Selepas kipas dihidupkan, tekan butang ini untuk memilih kelajuan kipas. Kelajuan akan meningkat setiap kali butang ini ditekan berulang kali. Kelajuan maksimum ialah 10.

BUTANG TIMER

Butang Timer boleh ditekan berulang kali untuk menambah masa penghantaran udara dalam kenaikan satu jam, sehingga maksimum 10 jam. Jangan gunakan fungsi pemasa jika kipas perlu beroperasi secara berterusan, kerana tiada LED pemasa yang akan menyala.

BUTANG OSC

Tekan butang ini untuk mengaktifkan fungsi ayunan. Untuk memilih arah tertentu, tekan butang semasa kepala kipas menghadap ke arah tersebut. Jika tidak, putarkan kepala kipas secara manual untuk mencapai julat ayunan yang lebih luas.



BUTANG MODE

Tekan butang ini untuk memilih mod. Urutannya adalah Normal, Semula Jadi, dan Tidur apabila butang ini ditekan berulang kali.

MOD NORMAL

Kipas beroperasi secara berterusan mengikut kelajuan yang dipilih.

MOD NATURAL


Kipas berfungsi pada kelajuan yang diprogramkan untuk meniru angin semula jadi. Setiap kali gear berubah, kipas akan beroperasi selama 3 saat sebelum beralih ke gear seterusnya, berulang secara berterusan.

MOD SLEEP

Kipas beroperasi pada kelajuan yang telah dipratetap oleh program komputer yang mensimulasikan "angin tidur." Fungsi ini menawarkan lima tahap tetap (1 hingga 5). Setelah diaktifkan, anda boleh melaraskan tahap menggunakan butang kawalan.

ALAT KAWALAN JAUH

1. Halakan alat kawalan jauh ke arah kipas dan tekan butang yang diinginkan.
2. Alat kawalan jauh boleh berfungsi pada jarak sehingga kira-kira lima meter dan sudut 30 darjah dari paparan LED panel.
3. Pastikan tiada cahaya matahari langsung menghala ke arah yang sama.
4. Keluarkan bateri sebelum membuang alat kawalan jauh.



Alat Kawalan Jauh

BATERI

1. Luncurkan penutup ruang bateri.
2. Masukkan bateri dan pastikan bateri diletakkan seperti yang ditunjukkan dalam rajah Ruang Bateri.
3. Luncurkan semula penutup bateri.

Nota: Jangan gunakan bateri boleh cas semula.



Bateri CR2025



Penutup Bateri

PELARASAN KECONDONGAN

Untuk melaraskan aliran udara ke atas atau ke bawah, tolak gril dengan ringan ke arah yang dikehendaki.

PELARASAN KETINGGIAN

Tiang pendirian bawah boleh ditanggalkan untuk melaraskan kepada ketinggian yang lebih rendah.

FUNGSI MEMORI

Selepas dimatikan secara manual dalam mod operasi semasa, apabila dihidupkan semula, kipas akan kembali ke tetapan terakhir sebelum dimatikan.